

FIG.1




FIG.2




FIG.3




FIG.4




FIG.5




FIG.6




FIG.7






VIBRATION BUTTON	INSTRUCTION	VIBRATION PATTERN
303	RIGHT TURN	
304	LEFT TURN	
305	GO STRAIGHT	
306	PRESENCE OF OBSTACLE	
307	OTHER	

FIG.8




FIG.9




FIG.10




FIG.11




FIG.12




FIG.13




FIG. 14




FIG. 15